


TORSTEN POST TOP LENS SWITCH





Step 1: Take off the 4 screws on the top of the fixture.



Step 2: Open the top cover, you can see two pcs of lens are installed in opposite direction(T5). Take off the screw from the lens(the right one), then turn lens on the right to the same direction as the left lens. Put the screws back to the lens, tighten the screws. Close the cover and tighten the 4 screws on the top of the fixture.

TORSTEN POST TOP LENS SWITCH

T5



T3

